



CONTENTS

WELCOME TO SOTA	2
BEFORE USING	2
LEARN MORE	2
COMPLETE UNIT INCLUDES.....	2
DO NOT USE.....	3
CAUTIONS	3
SUMMARY OF LIGHTS	3
HOW TO USE THE WATER OZONATOR	3
Typical Use.....	5
TIMING TO SATURATE WITH OZONE	6
STERILIZING WATER.....	6
WATER DISINFECTION TESTS	6
ELECTRICAL SPECIFICATIONS	7
Power Requirements.....	7
Optional Power Input.....	7
Output Specifications.....	7
Ozone Generator Construction	7
TROUBLESHOOTING	7
COUNTRIES THAT PARTICIPATE IN MANUFACTURING	7
REPLACEMENT ACCESSORIES	7
WARRANTY.....	8
REPAIRS.....	8

WELCOME TO SOTA

Thank you for allowing us to be a part of your wellness team.

The Water Ozonator is a consumer product designed to be used as part of a Wellness Lifestyle. A commitment to healthy lifestyle choices is an important factor in the journey to Wellness.

The SOTA Water Ozonator produces freshly-ozonated water. The fresh taste and extra oxygen are an energizing way to hydrate your body.

The Water Ozonator is designed to be used independently, but can also be used together with any of the SOTA Products.

With proper care, your Water Ozonator should provide you many years of trouble-free use.

Please understand that results will vary.

BEFORE USING

Please read the manual thoroughly before using your Water Ozonator. For the most up-to-date manual, please visit our website www.sota.com/manuals.

We've made every effort to ensure the information in your manual is up-to-date at the time of printing ... since that time however, new information may have become available.

LEARN MORE


To learn more about the Water Ozonator we invite you to visit the SOTA website:

www.sota.com

The website offers How to Videos, Frequently Asked Questions, *The SOTA Products User Guide*, SOTA News ... and more.

COMPLETE UNIT INCLUDES

- One (1) Water Ozonator Unit
- One (1) Airstone and Tubing Set
- One (1) Wall Adaptor
- One (1) Carrying Case
- One (1) Product Manual



DO NOT USE

1. As with all electrical products do not use near water, when driving a car or when operating heavy equipment.

CAUTIONS

1. Avoid breathing the ozone directly from the Airstone as it may irritate lung tissue. Use in a well-ventilated area, such as under a stove top exhaust fan.
2. Do not operate the unit without the built-in air pump running. If the air pump is not running there will be no bubbles coming from the airstone.
3. While this technology is generally considered safe, there exists potential for rare individual reactions that cannot reasonably be foreseen. Therefore, your use of the SOTA Products constitutes your agreement that you are responsible for your decision to use the technology and that you hold SOTA harmless for any injuries or damage believed to arise from using the SOTA Products.

SUMMARY OF LIGHTS

GREEN: Indicates the unit is on as well as the timing selected.


HOW TO USE THE WATER OZONATOR

1. Insert the power plug from the AC-DC Wall Adaptor into the unit and plug the adaptor into an electrical outlet.
2. Connect the silicone tubing to the ozone outlet pipe on the side of the Water Ozonator.

Note: To make it easier to connect, dip the end of the silicone tubing in water. The silicone tubing will then slip on easier.

3. Submerge the Airstone, attached to the silicone tubing, in a glass container of water. Use a glass container as glass is ozone resistant.

- a. Chilled water holds more ozone but room temperature water is healthier for the stomach.



b. It is important to place the water with submerged airstone in a well-ventilated area, as concentrated ozone in air may irritate lung tissue. For example, under a stove-top fan. Place the container of ozonating water well away from the ozone unit.

Note: Ozonating liquids other than water may clog the airstone and will void the warranty.

4. Push the ON/OFF/TIMER button to turn the unit ON. All the lights will flash in sequence to indicate the unit is ready for use.

a. The unit starts with the 5 minute timer cycle.

b. If more than 5 minutes is required, push the ON/OFF/TIMER button – each push moves the timer from 15, to 30, to 60 minutes. A GREEN flashing light indicates which time is set. See page 6 for timing.

5. Check to be sure fine bubbles pass out of the Airstone into the water. If you do not see any bubbles, ensure the silicone tubing is firmly attached to the ozone outlet on the side of the unit. As the unit operates, you should catch the smell of ozone.



6. At the end of a timed session, the unit will beep, all the LED lights will flash, and the air pump will continue to operate for an additional 10 seconds to purge the ozone from the tube. The unit will then turn itself OFF.

Allow water to drain from the tubing after use. This ensures water will not drain back into the unit.

7. Use the freshly ozonated water *immediately* for optimal results. If left for 20 minutes in open air, the ozone dissipates out of the water and the benefits of the extra oxygen will no longer be present.

8. To turn the unit OFF at any time, hold the ON/OFF/TIMER button down for a full two seconds.

9. Turn the unit off and *unplug the wall adaptor* when not in use.

Notes:

Temperature of Water: Chilled water holds more ozone, however room temperature water is healthier for the stomach.

Timing: When the timer is set for 15, 30 or 60 minutes, the lights indicate remaining time. For example, when set for 60 minutes, the GREEN 60 minute LED flashes continuously. As time progresses, the GREEN 30 minutes LED comes on as well to indicate there is 30 minutes or less remaining. As time progresses, the 15 and then 5 minute LEDs will each come on to indicate the time remaining.

Storage: Larger quantities of ozonated water can be stored in a thermos or glass container with an air-tight lid. The amount of ozone in the water will continue to dissipate, eventually leaving no ozone in the water.

Charcoal filter: A charcoal filter inside the unit protects the circuit from the ozone in air. Excess beads of charcoal may fall off the filter and out of the unit. This is normal. Simply discard the beads.

Pump: If the built-in air pump stops running, turn the unit off and contact your closest repair depot. See page 8.

TYPICAL USE

Quantity: It is usually best to gradually increase the intake of ozonated water. To begin, it is suggested to ozonate only one glass of water a day. If well tolerated, increase to two or more glasses of ozonated water daily.

Length of Use: The SOTA Products User Guide available at www.sota.com/spug offers suggestions for Focused, Basic and Ongoing Wellness Plans.

General Guideline: 16 ounces (500 ml) or more a day. If using for an extended period, it is wise to take breaks.

TIMING TO SATURATE WITH OZONE

One cup of cold purified water is saturated with ozone within 2 minutes to over 1,000 mV ORP (Oxidation Reduction Potential). The 5-minute setting is sufficient to ozonate up to 4 cups (1 quart or 1 liter) of purified water for either room temperature or ice water. Set the timer depending on the quantity of water to saturate with ozone.

Quantity of Water	Timed Setting
4 cups (1 quart or 1 liter) or less	5 minutes
1 gallon or 4 liters	15 minutes
2 gallons or 8 liters	30 minutes
4 gallons or 16 liters	60 minutes

STERILIZING WATER

The output of the Water Ozonator is sufficient to sterilize water. It does not remove impurities such as heavy metals - a water filtration system is needed for that. The amount of time required to sterilize water depends on the degree of contamination of the water. The timing in the table above is for saturation only. More time may be required to sterilize water.

WATER DISINFECTION TESTS

Tests by two independent laboratories proved the effectiveness of the ozone generated by a SOTA Water Ozonator in killing the following virulent pathogens:

Escherichia coli (E coli)	Salmonella spp (typhoid fever)
Pseudomonas aeruginosa	Shigella spp
Staphylococcus aureus	Proteus mirabilis
Klebsiella spp	Candida spp

ELECTRICAL SPECIFICATIONS

POWER REQUIREMENTS

12 Volts DC @ minimum 1.5 Amps, **Tip or Center Positive**.

Caution: Exceeding the voltage rating or reverse connection may result in injury or unit failure. This will **void** the warranty.

OPTIONAL POWER INPUT

To operate the ozone generator from a 12 Volt DC source such as an automobile battery, or an appropriate solar panel, purchase a Universal Power Cord with **Tip or Center Positive** polarity.

OUTPUT SPECIFICATIONS

Greater than 200 mg/Hr O₃ @ 1.5 LPM. Measured using an Ozone-in-Air GM Anseros Ozone Analyzer, Model Ozomat GM 6000-RT. Ozone concentration is 3.6 Gamma (mg/l or ug/ml) @ 0.5 LPM.

Pump outputs 0.5 PSI pressure, 2 LPM (2000 cc/min) volume.

OZONE GENERATOR CONSTRUCTION

Uses Fused Quartz Glass and High Grade Stainless-Steel ozone chamber. With normal use, the chamber should last several years.

TROUBLESHOOTING

A Troubleshooting Guide for the Water Ozonator is available at www.sota.com/manuals. This Guide is a great tool to check if you are experiencing any issues with your unit.

COUNTRIES THAT PARTICIPATE IN MANUFACTURING

The manufacturing of the SOTA Products is a global collaboration. The following countries participate in the making of the Water Ozonator (listed in alphabetical order): **Canada, China, Hong Kong, Malaysia, Spain, Taiwan, Thailand and the USA.**

REPLACEMENT ACCESSORIES

To replace your accessories, please contact your supplier.



WARRANTY

The Water Ozonator Model WOZ5 is covered by a two (2) year limited warranty. Please keep proof of purchase. Warranty is void if the failure is due to abuse, negligence or if pure oxygen is used. SOTA reserves the right to make changes to the Water Ozonator without obligation.

REPAIRS

Please contact your supplier for return instructions. For information about your closest repair depot, contact repairs@sota.com or call 1.250.770.2023 or 1.800.224.0242 (toll-free in Canada & USA).



Made in China. Designed and Engineered in Canada.

• The SOTA units are consumer products designed to be used as part of a Wellness Lifestyle • The SOTA units are not medical devices nor are they intended to diagnose, treat or cure any medical or health condition • The use, safety or effectiveness of the SOTA units has not been approved by any government agency • Please consult a health practitioner for any medical or health condition • Results using the SOTA Products will vary for each person • Please note that all purchases of SOTA Products are deemed to be made in Penticton, BC, Canada •